



PVC WIRE NETTING INSTALLATION With T-Posts




THINGS YOU'LL NEED


- [PVC coated wire netting](#)
- [T Posts](#)
- Tape measure
- Post driver or mallet
- [Cable ties](#)
- Spirit level
- String
- [Pegs](#)
- [Tensioning wire](#) (optional)
- Plier (optional)
- Spade
- Cement (optional)

INSTRUCTIONS**Step 1: Mark Area**


Draw a straight line for the fence between the two posts located at each end.

**Step 2: Measure Post Distance**

Employ a tape measure to mark the positions of the posts, ensuring they are spaced 2 to 3 meters apart. To improve stability, reduce the distance between your fence posts.


**Step 3: Install End Posts**

Use a post driver or mallet to embed the end posts 50cm into the ground. Ensure that the holes of the posts are oriented towards each other to maintain consistent alignment.




Step 4: Check for Same Height

Secure a length of string between the end posts, then verify that they are installed at the same height by employing a tape measure.




Step 5: Check for Straightness

Use a spirit level to confirm that the posts have been installed completely straight.



Step 6 (Optional): Set in Concrete

For a stronger and more secure fence, place your posts in concrete by excavating a 50cm hole and pouring cement for the post to settle in.




Step 7: Install Middle Posts

To set up middle posts, repeat steps 3 through 5.

Make sure that the posts are oriented in the same direction and are installed both straight and at equal heights.


You may also reinforce the middle posts with concrete for additional strength.



Step 9 (Optional): Install Tension Wire

When working with lightweight mesh, consider attaching a tension wire between the end posts to prevent any potential sagging.


Wrap the tension wire around the hole of the end posts and secure it by twisting the end of the wire with pliers.



Step 10: Secure Mesh to End Post

Fasten the mesh to the end post using cable ties, threading them through the pre-drilled holes in the post.


You can further reinforce the attachment by adding additional cable ties around the entire post.



Step 11: Pull Taut

Pull the mesh taut and then fasten it to the second post using cable ties, being careful not to pull too tightly.

Repeat this procedure until you reach the end post.



Step 12 (Optional): Secure to Tension Wire

If you've installed a tension wire, use cable ties to secure the mesh to it, spacing them roughly 30-45 cm apart.

