



STAINLESS STEEL MESH INSTALLATION With Wooden Posts




THINGS YOU'LL NEED

- [Welded wire mesh](#)
- Wooden posts
- Pliers
- Hammer
- Wire cutters
- [Staples](#) or [Cable ties](#)
- [Pegs](#) (additional)
- Spade (optional)
- Cement (optional)


INSTRUCTIONS**Step 1: Mark the Post Location**

Identify the positions of the posts, maintaining a distance of 2-2.5 meters between each post.

**Step 2: Dig Holes**


Dig holes for the posts, making sure they are approximately one-third of the post's length deep.

Confirm the vertical alignment of the posts using a spirit level.

**Step 3: Cement Posts In (Optional)**

After filling the holes with concrete, position your posts within the concrete.


Utilize a spirit level to ensure that the posts are perfectly upright.



Step 4: Secure Mesh to End Post


Obtain sufficient mesh to span the distance between the initial two posts.

Secure the mesh to the posts using staples or cable ties at intervals of 15 cm.



Step 5: Repeat Step 4

Proceed with fastening the remaining portion of the mesh by adhering to the procedure described in step 4.



Step 6: Secure Mesh to Last Posts

Secure the mesh to the final posts to complete the installation of the fencing.